





КАТАЛОГ ЗАПАСНЫХ ЧАСТЕЙ
ЗАТИРОЧНАЯ МАШИНА **VILAR M6**



vilar.pro
info@vilar.pro




Номер по схеме	Количество в комплекте
A	1
B	1
C	1
D	1
E	1
F	1
G	1
H	1
I	1




Номер по схеме	Количество в комплекте
1	2
2	1
3	1
4	1
5	2
6	1
7	2
8	1
9	1
10	1
11	1
12	1
13	4
14	4
15	4

Комплект "А"




Номер по схеме	Количество в комплекте
1	1
2	1
3	1
4	1
5	1
6	1
7	1
8	1
9	1
10	1
11	1
12	1
13	1
14	1
15	1
16	1

Комплект "B"




Номер по схеме	Количество в комплекте
1	1
2	1
3	1
4	1
5	4
6	1
7	1
8	1

Комплект "С"




Номер по схеме	Количество в комплекте
1	1
2	4
3	4
4	4
5	4
6	1
7	1
8	1
9	1
10	4
11	4
12	4
13	4
14	1
15	1
16	1
17	1
18	1
19	2
20	2
21	1
22	1
23	4

Комплект "D"




Номер по схеме	Количество в комплекте
1	8
2	1
3	2
4	2
5	2
6	1
7	1
8	1
9	1
10	1
11	1
12	1
13	1
14	1
15	1
16	1
17	1
18	1
19	1
20	1
21	8
22	1
23	1
24	1
25	1
26	1
27	1
28	1
29	4
30	4

Комплект "Е"




Комплект "F"

Номер по схеме	Количество в комплекте
1	1
2	2
3	2
4	1
5	2
6	2
7	2
8	4
9	4
10	4
11	1
12	2
13	2
14	2
15	2
16	1
17	1
18	2
19	1
20	6
21	6
22	6



Номер по схеме	Количество в комплекте
1	1
2	1
3	1
4	1
5	1
6	1
7	4
8	4
9	4
10	4
11	4
12	4
13	4
14	8
15	8
16	8
17	4
18	4
19	4
20	4

Комплект "G"



Номер по схеме	Количество в комплекте
1	1
2	1
3	1
4	1
5	2
6	2
7	3
8	1
9	1
10	1
11	2
12	2
13	1

Комплект "Н"